

TO: SOL LEVY
FROM: H. LAWROSKI
SUBJECT: TENTATIVE QUALIFICATION OF MAKEUP
TANK SYSTEM UP TO MU V13

Apr 11 12, 1979
1:00 P.M.

1. Place a qualified monitor at or in the air exhaust from Auxiliary Building. Calibrate with Range 0-100 mr reading of gas stream.
2. Close MU V13 and all inlet and outlet from makeup tank.
3. Read pressure and level.
4. Pressurize with N_2 up to 5 or 10 psi and secure.
5. Maintain isolation for 2 hours, if possible.
6. Record pressure and radiation readings every 10 minutes.
7. Open MU V13 to vent header and return to normal op.

166 095

7 905230 480

P